

## RYLR993 and LoRaWAN® Network reference





























## 1. What is LoRaWAN?

The LoRaWAN® specification is a Low Power, Wide Area (LPWA) networking protocol designed to wirelessly connect battery operated 'things' to the internet in regional, national or global networks, and targets key Internet of Things (IoT) requirements such as bi-directional communication, end-toend security, mobility and localization services. For more details, please refer to <a href="https://lora-reference.com/https://l alliance.org/

## 2. Instruction of how to use RYLR993 and LoRaWAN® Network for data transmission

First you must obtain a Gateway containing the LoRaWAN network service

You must get "Device EUI", "App EUI" and "App Key" from LoRaWAN® service provider. These three data are the account ID and password that used by the RYLR993 module to connect to the Helium Network.

The following describes the simple usage process. For advanced usage commands, please refer to the RYLR993 AT Command file.

**2.1** Boot Information: The following strings will be occurred after you Boot or RESET:

BAND:US915

'Stands for the current frequency Band

+READY

2.2 Set Frequency Band: After sending "AT+BAND=0", RYLR993 will response as below

BAND:AS923

OK

**2.3** Test the response of RYLR993: After sending "AT", RYLR993 will response as below

OK

2.4 Set DEUI: After sending "AT+DEUI=60:81:F9:AF:21:68:5C:5F", RYLR993 will response as below

OK

2.5 Set APPEUI: After sending "AT+APPEUI=60:81:F9:6B:CA:11:C0:17", RYLR993 will response as below.

OK

2.6 Set NWKKEY: Because Helium Network is an APP itself, therefore the NWKKEY in RYLR993 is, after APPKEY send "AT+NWKKEY=FA:74:AF:C5:95:7A:B7:BF:52:E3:6F:AE:EA:C1:BA:D5:", RYLR993 will response as below

OK

**2.7** Log in to LoRaWAN® Network: After sending "AT+JOIN=1", RYLR993 will response as below

OK

+EVT:JOINED

'Successfully Login to Helium Network

+EVT:RX 1, DR 0, RSSI -19, SNR 8

'The quality of the signal status

**2.8 Sending data to LoRaWAN® Network :** After sending "AT+SEND=1:1:31323334", RYLR993 will response as below

OK

+EVT:SEND CONFIRMED

'Confirmation of sending data successfully

+EVT:RX\_1, DR 2, RSSI -18, SNR 7

'The payload field are the data that has been uploaded successfully, and the format is BASE64



## 4.9 Receive the data transmitted from LoRaWAN® Network to RYLR993:

As the figure shown below, 12345678 in Text format can be transferred to RYLR993

Due to LoRaWAN® Network can only download the data when RYLR993 is uploading the data, therefore it is needed to send "AT+SEND=1:1:31323334:", and RYLR993 will response as below

OK

+EVT:SEND\_CONFIRMED

+EVT:1:08:3132333435363738

'Confirmation of sending data successfully

+EVT:RX\_1, DR 2, RSSI -28, SNR 7





E-mail: sales@reyax.com Website: http://reyax.com